

• Installing the device



Fig.1



Fig.2

1. Unlock the front door by inserting the key provided, turning the key counterclockwise. Pull to open the front door.
(Fig.1 ~ Fig.2 CKDF only)



Fig.3a for CKDF




Fig.3b for CPF

2. Remove the HDD carrier away from the body.
(Fig.3a) (Fig.3b)




Fig.4

3. Use the miniature key and insert into the key hole to eject handle. (Fig.4)



Fig.5

4. Pull the handle outwards to remove the carrier away from the body. Remove the carrier support away. (Fig.5)



Fig.6

5. Secure the HDD to the carrier using the four 6#-32 screws provided.
(Fig.6)



Fig.7a for CKDF



Fig.7b for CPF

6. Insert the carrier along with HDD into body. Match the two sides of carrier to the anti-shock rails located at the left and right sides inside the body. (Fig.7a) (Fig.7b)



Fig.8a for CKDF

7. Keep the handle angled from the carrier, then slide the carrier along the anti-shock rails and into the body until fully inserted. (Fig.8a) (Fig.8b)



Fig.8b for CPF



Fig.9

8. Push the handle towards the carrier until "click" to completely secure the position of carrier. (Fig.9)



Fig.10a for CKDF



Fig.10a for CPF

9. Close the front door and lock the key lock by turning the key clockwise to complete HDD installation. (Fig.10a) (Fig.10b)

Note :

- (1) HDD failure will Indicate Red only when signal is inputted by controller.
(please refer to HDD -Fail signal)
- (2) Please terminate the last connector using a terminator.
- (3) The above testing results were obtained under the surrounding temp at 25°C.

Once any further requirement about product application or more related product information, please access to: www.icydock.com.